


V7 IFP HDMI CEC & Sound ARC

How to enable HDMI CEC & Sound ARC function

HDMI CEC function is OFF by default. Sound ARC is disabled when HDMI CEC is OFF.

To enable CEC and Sound ARC, use the IFP remote control and enter "INPUT 1 3 7 9" to enter the DEBUG MENU, and select the HDMI Setting.



Notes: The function is only available on port HDMI 2 (HDMI 1.4 input)

V7 IFP HDMI CEC & Sound ARC

Item	Function	Detail
HDMI CEC-ON	When the IFP is turned OFF/ON, the signal input device will be turned OFF/ON by followed.	You can use remote controller to operate the signal input device, the available key is Upper-bottom-left-right, number 0-9, Back.
Sound ARC-ON (HDMI CEC-ON)	When the IFP is turned off, the input device is turned off	/
	When IFP is turned on, the input device is turned on.	Switch channel to HDMI2, the amplifier of IFP and input device is turned on.
		Connect the input device, the speaker of IFP is silent, and the audio output to amplifier is normal.
		You can use remote controller to adjust the audio of input device.
HDMI CEC-OFF	When IFP is turned off, input device will not be turned off	HDMI CEC function is OFF by default; Sound ARC is disabled when HDMI CEC is OFF Input device can't be operated by remote controller
Sound ARC-OFF (HDMI CEC-ON)	When the IFP is turned OFF/ON, the signal input device cannot be turned OFF/ON by followed.	Switch channel to HDMI2, the amplifier of IFP and input device cannot be turned on
		Connect the input device, the speaker of IFP and audio output to amplifier is normal
		You cannot use remote controller to adjust the audio of input device
		The audio of speaker is normal in all channels